



Integrated Design Capability / Instrument Design Laboratory

Ocean Color Experiment Ver. 2 (OCE2)


Delta Study ~ Concept Presentations ~ Mechanical Systems

Ed Aguayo

Dave Palace

April 27, 2011

*Do not distribute this material without permission
from the Scientific Point of Contact Jay Smith (James.C.Smith@nasa.gov)
or the Programmatic Point of Contact Angela Mason (Angela.J.Mason@nasa.gov)
This document contains sensitive information and is intended for NASA Official Use Only*



N A S A G O D D A R D S P A C E F L I G H T C E N T E R

Mechanical Systems Work






Integrated Design Capability / Instrument Design Laboratory

- Using the design from GOCECP as a baseline template
- Three Main Assemblies
 - Scan Drum And Assembly Mechanism—Telescope, optics, and mechanism that spins the telescope
 - Aft Optics/Detector Assembly—Detectors, Fiber Optics
 - Cradle Assembly—Tilting Mechanism, calibrating mechanism, I/F to Spacecraft
- Main structural Materials used
 - Al 6061-T6
 - Aluminum Honeycomb




Instrument Packaging Overview

Integrated Design Capability / Instrument Design Laboratory






Scan Drum and Mechanism Assembly

Integrated Design Capability / Instrument Design Laboratory



Scanning Telescope Assembly


Integrated Design Capability / Instrument Design Laboratory






Aft Optics/Detector Assembly

Integrated Design Capability / Instrument Design Laboratory



Detector Array Assembly


Integrated Design Capability / Instrument Design Laboratory




Trade to Add Third Brace

Integrated Design Capability / Instrument Design Laboratory

- Analysis only performed for Baseline, but can be used as a general indication for Delta study
- Used FEA to compare advantages of 2 vs 3 braces holding the Detector Array Mounting Plate
 - Simple model using Bar and Plate Elements
 - Mass of Six Pack Assemblies modeled as non-structural mass



VS





FEA Results


Integrated Design Capability / Instrument Design Laboratory

- First mode for two braces 13Hz

First mode for three braces 21Hz





Side Support for Detector Array Structure Assembly




Integrated Design Capability / Instrument Design Laboratory

- First mode still low, add support by connecting to Aft Structure Side Panel
 - Increase First Mode to 41Hz which is likely acceptable (need structures blessing)
 - Might need to further increase stiffness

Attach Detector
Array Structure
Assembly to Aft
Structure Side Panel
Here







Preliminary FEA of Detector Array Structure Assembly


Integrated Design Capability / Instrument Design Laboratory

- Material: Al 6061-T6
- Allowable Assumed (yield): 32ksi
- FS: 1.25
- Max stress: 8.1ksi
- Margin of Safety: $(32)/(8.1 \times 1.25) - 1 = \underline{+2.16}$



Detector Six Pack

Integrated Design Capability / Instrument Design Laboratory





Note: Lens/Detector Assembly = Optics Tube Assembly + Detector Assembly

Lens/Detector Assembly

Integrated Design Capability / Instrument Design Laboratory


Based on ATLAS Design



Note: Material to be used for the Optics Tube and Detector Housing is baselined as Aluminum. Depending on temperature excursions of the assembly and optical alignment tolerances, it might be necessary to use Titanium instead.


ATLAS Optics Tube

Integrated Design Capability / Instrument Design Laboratory



Fiber Optic Routing


Integrated Design Capability / Instrument Design Laboratory



Fiber Support Plates have C-channels to route the Fiber optics. It guides them and maintains minimum bend radii


Cradle Assembly

Integrated Design Capability / Instrument Design Laboratory



Radiator

Integrated Design Capability / Instrument Design Laboratory



Radiator attaches to structure using two Al 6061-T6 brackets. If there is a thermal gradient between the radiator and the structure, it is possible to add a flexure set between the brackets and the radiator.

Concerns



Integrated Design Capability / Instrument Design Laboratory

- **Alignment of Optics Tube components and Detector Assembly**
 - Labor intensive for 144 Assemblies if tolerances are tight and alignment needs to be done “by hand” (as opposed to using machine tolerances)
- **Routing of Fiber optics**
 - Difficult Assembly (routing)
 - Nested assembly would make it difficult to disassemble
- **Alignment of fiber bundle to HAM to Telescope**
- **Radiator is large and heavy**
 - Need further analysis to ensure structure to attach radiator to instrument provides adequate support

